

1 Before driving

1-1. Hybrid system.....	2
Hybrid system.....	2
1-2. Key information	11
Keys	11
1-3. Opening, closing and locking the doors and trunk	13
Smart access system with push-button start	13
Wireless remote control.....	22
Doors.....	25
Trunk.....	29
1-4. Adjustable components	33
Front seats.....	33
Driving position memory system	35
Head restraints.....	38
Seat belts	40
Steering wheel.....	46
Inside rear view mirror.....	47
Outside rear view mirrors.....	48
1-5. Opening and closing the windows and moon roof.....	50
Power windows.....	50
Moon roof	52

1-6. Refueling.....	55
Opening the fuel tank cap.....	55
1-7. Theft deterrent system.....	59
Hybrid vehicle immobilizer system	59
Alarm.....	61
Theft prevention labels (U.S.A.).....	63
1-8. Safety information.....	64
Correct driving posture	64
SRS airbags	66
Front passenger occupant classification system.....	77
Child restraint systems	82
Installing child restraints	85

2 When driving

2-1. Driving procedures.....	96
Driving the vehicle.....	96
Starting the hybrid system.....	103
Transmission	106
Turn signal lever.....	110
Parking brake	111
2-2. Instrument cluster	112
Gauges and meters	112
Indicators and warning lights	116
Multi-information display.....	119

2-3. Operating the lights and windshield wipers	122
Headlight switch	122
Fog light switch	125
Windshield wipers and washer	126
Headlight cleaner switch	128
2-4. Using other driving systems	129
Cruise control	129
Dynamic radar cruise control	132
Intuitive parking assist	141
Rear view monitor system	160
AVS (Adaptive Variable Suspension System)	163
Driving assist systems	164
PCS (Pre-Collision System)	169
2-5. Driving information	172
Cargo and luggage	172
Vehicle load limits	175
Winter driving tips	176
Trailer towing	181
Dinghy towing	182

3 Interior features

3-1. Using the touch screen	184
Touch screen	184
Setting the touch screen	187
3-2. Using the air conditioning system and defogger	192
Automatic air conditioning system	192
Rear window and outside rear view mirror defoggers	199
3-3. Using the audio system	200
Audio system type	200
Using the radio	203
Using the cassette player	212
Using the CD player	216
Playing MP3 and WMA discs	224
Using the DVD player	232
Playing DVD video/audio	235
Playing video CD	247
DVD player and DVD video disc information	251
Optimal use of the audio/video system	255
Using the steering switches	259

TABLE OF CONTENTS

Index

3-4. Using the hands-free system.....	261
Hands-free system	261
Using the Bluetooth® phone	265
Setting the hands-free system	278
3-5. Using the interior lights	303
Interior lights list.....	303
3-6. Using the storage features.....	306
List of storage features.....	306
3-7. Other interior features.....	312
Sun visors.....	312
Vanity mirror	313
Clock.....	314
Outside temperature display	315
Ashtrays	316
Cigarette lighter	317
Power outlet.....	318
Seat heaters.....	319
Seat heaters and ventilators	321
Armrest	323
Rear sunshade.....	324
Floor mats.....	326
Trunk features.....	327
Garage door opener.....	329
Compass.....	334
Lexus Link System	338

4 Maintenance and care

4-1. Maintenance and care.....	352
Cleaning and protecting the vehicle exterior	352
Cleaning and protecting the vehicle interior.....	354
4-2. Maintenance.....	357
Maintenance requirements	357
General maintenance.....	359
Emission inspection and maintenance (I/M) programs	362
4-3. Do-it-yourself maintenance.....	363
Do-it-yourself service precautions	363
Hood.....	366
Positioning the jack	367
Engine compartment.....	369
Tires	383
Tire inflation pressure.....	393
Wheels.....	397
Air conditioning filter	399
Electronic key battery	401
Checking and replacing fuses.....	403
Headlight aim.....	419
Light bulbs.....	421

5 When trouble arises

5-1. Essential information	428
If your vehicle needs to be towed.....	428
If you think something is wrong	435
Event data recorder	436
5-2. Steps to take in an emergency	438
If a warning light turns on or a warning buzzer sounds.....	438
If a warning message is displayed.....	444
If you have a flat tire (Vehicles with run-flat tires)	460
If you have a flat tire (Vehicles with standard tires)	461
If the hybrid system will not start	471
If the shift lever cannot be shifted from P	472
If you lose your keys	473
When the electronic key battery is discharged	474
If the 12 volt battery is discharged	476
If your vehicle overheats	480
If the vehicle becomes stuck.....	483

6 Vehicle specifications

6-1. Specifications.....	486
Maintenance data	486
Fuel information.....	495
Tire information	498
6-2. Customization	510
Customizable features	510
6-3. Initialization	514
Items to initialize	514

7 For US owners

Reporting safety defects for U.S. owners.....	516
---	-----

Index

Alphabetical index.....	518
What to do if.....	526